

On-site Wastewater Management Training Course

Irrigation Systems

Componentry, Selection and Design

Centre for Environmental Training




Irrigation Systems

- As effluent quality is not always consistent or compliant, it is important to minimise public health and environmental risks, especially if irrigation is at the surface
- Whilst irrigation area sizing is important, it is equally important to select, match and configure the components of an irrigation system as part of a hydraulic design, to ensure effective even distribution and compliant operation

Centre for Environmental Training



What Makes Up an Irrigation System



Centre for Environmental Training



Treatment System

- Secondary or better
- Commonly AWTS
- May be sand or media filter, mound or reed bed
- May require non-return valve to prevent backflow
- May require pressure reducing valve



Centre for Environmental Training




Dosing System

- Commonly pump driven
- May be low pressure dosing device such as a Flout or siphon (for LPED)
- Tipping bucket not appropriate – dose too small and will not pressurize dripper line
- AS/NZS 1547:2012 recommends minimum 200L/dose
- Should be 2-3 x system fill volume
- Larger volumes result in better field distribution

Centre for Environmental Training



Dose Volume




Centre for Environmental Training



Demand Dosing vs Timed Dosing

- Demand dosing by float switch most common in domestic systems
- Timed dosing significantly better. More common in non-domestic systems



Centre for Environmental Training



Ensuring Even Distribution

- Float switches do not balance shock wastewater loads
- Constrained sites may require a balance tank and timer controlled pump to avoid saturation and ensure even distribution over time
- Large areas may require division into several zones using an indexing / sequencing valve
- A high level alarm should be fitted to the system to warn of system failure

Centre for Environmental Training



Pump Selection


- Needs to be appropriate for wastewater
- Made of non-corrosive materials
- Correct hydraulic duty (Flow (Q) and Head (H)) for actual operating point of the system
- Operating point needs to be as close to optimum efficiency point (mid-point on pump curve) as possible
- Need to determine appropriate operating point
- Affordability – beware cheap pumps

Centre for Environmental Training



Pump Selection


- Pump performance is described by a pump curve
- In terms of Flow (Q) and Head (H)



Centre for Environmental Training



Pump Selection



Centre for Environmental Training



Pump Selection

- Surface irrigation systems with rotary sprinklers and spray heads require ~4-10m head at the top of system with flow rates of 2-6L/min per sprinkler
- Subsurface irrigation systems typically require a 10-30m head operating pressure
- Pumps in many accredited AWTS/STS have:
 - 6-12m maximum head capacity
 - 33-130L/min maximum flow rate

Centre for Environmental Training



Pump Selection

- Sprinkler operating head + friction loss in the pipe commonly requires most if not all of the available head capacity (leaving limited capacity for static lift)
- Pumps supplied are often of insufficient capacity to uniformly irrigate correctly sized irrigation areas (based on appropriate DIR for soil type and/or water and nutrient balances), even when divided into a number of smaller sections or zones

Centre for Environmental Training 

Pump Selection

- Uneven effluent distribution is a significant contributor to poor AWTS performance, or failure
- Irrigation area sizing requirements may create need for a bigger pump than typically supplied
- A one size fits all approach to pumps is not practical
- Pump should be selected to meet the specific requirements of each site

Centre for Environmental Training 

Filtration

- Critically important
- Protects irrigation system from blockages
- Mesh filters low cost
- Disk filters higher performance



Centre for Environmental Training 

Filtration

- Filtration of effluent is essential for effective irrigation
- Cylindrical mesh filters are usually sufficient for surface irrigation systems (typically 150 mesh, 100 micron rated filters)
- Disc filters better protect subsurface irrigation systems
- Need regular cleaning as part of each service
- If filter clogs frequently, need to investigate and solve treatment system problem

Centre for Environmental Training 

Flushing


- Again, critically important
- Scours potential blockages
- Can return flush line to treatment system, or field flush to soak away (gravel pit)
- Flush valves can be automatic or manual
- Automatic flush flushes ~4 litres on start-up



Centre for Environmental Training 

Automatic Flush Valve

- Netafim Automatic Flushing Valve



Centre for Environmental Training 

Flushing Velocity

- Flushing velocity can be calculated using the continuity equation (part of hydraulic design)
- Must be sufficient to entrain air and sediment in lines and prevent build-up of slimes
- Dirtier water requires higher velocities
- Typically >0.8m/sec required for effluent
- Some driplines rated >0.3m/sec

Centre for Environmental Training 

Distribution System

- Mainline to field
- Indexing / sequencing valve
- Manifold
- Laterals
- Drippers or sprinklers
- Air valve / vacuum valve
- Dripper line non-leakage (DNL) valves
- Flush valve / Field flush / Flush return line

Centre for Environmental Training 

Mainlines, Submains, Manifolds

- Typically 25mm ID or larger diameter LDPE or PVC lilac piping
- Manifold and laterals should be buried
- Older systems may sit on ground surface
- Most Councils now require burial
- Surface exposure increases potential for damage (e.g. mowers, animals) and degradation (e.g. exposure to UV)



Centre for Environmental Training 

Mainlines, Submains, Manifolds

Pipe selection is part of hydraulic design. Need to consider:

- Energy losses in pipe. Refer to manufacturer's charts or calculate
- Pressure rating - AS/NZS requires pipes to be rated at 150% of the shut off head (of the pump)
- Appropriate wall thickness and depth of burial to protect pipe
- Consider cost, including fittings

Centre for Environmental Training 

Indexing / Sequencing Valves

- Used to automate and sequentially deliver doses to each zone (zones generally <400m²)
- Improves hydraulic performance of the irrigation field and reduces demand on pump



Centre for Environmental Training 

Surface Irrigation

- Only suitable for slopes <10%
- Secondary treatment and disinfection required
- Wide variety of spray heads (rotary, impact, spray nozzles, drippers) and risers (fixed, spike, pop-up)
- There are only a limited range of spray heads specifically designed for domestic effluent irrigation (larger orifices), but many for clean water (smaller orifices, which readily block)
- Sprays must not generate runoff or aerosols and should have a throw and plume height suited to the site

Centre for Environmental Training 


Sprinkler Layout and Recommended Overlap

Average conditions:

$S = L = 60\%$ of the wetted diameter of sprinkler

Windy or exposed conditions:

$S = L = 50\%$ of the wetted diameter of sprinkler



Centre for Environmental Training

cet

Surface Irrigation

- Inappropriate where rainfall > evaporation and soils are saturated for extensive periods of time
- May result in uneven distribution



Centre for Environmental Training

cet

Subsurface Irrigation

- Subsurface drip irrigation is the industry standard
- Significant public health and environmental advantages over surface spray irrigation
- Involves pressure dosing of 13mm ID pipe fitted with turbulent flow or pressure compensating emitters, laid along the contour
- Built-in or dosed protection against root intrusion and biofilm development (copper oxide/Trifluralin)
- Typically lilac (purple) pipe

Centre for Environmental Training

cet


Subsurface Irrigation

- Places effluent directly in the root zone and prevents surface runoff during rainfall
- Allows more use of and ease of maintenance of an irrigation area
- Careful hydraulic design, layout and installation is essential (effluent filtration, line flushing, vacuum release valves, correct spacing of laterals / emitters etc.) is required; though this is often not undertaken

Centre for Environmental Training

cet

SSI Setup for 1,200L/day System on Category 4 Soil




ecoEng


Centre for Environmental Training

cet

Subsurface Irrigation System Layout



Revised Figure M1
Page 167
AS/NZS1547:2012 to ensure even pressure in lines for effective distribution and flushing



Centre for Environmental Training

cet

Pressure Compensating Dripper Line




Source: CIVCON

Centre for Environmental Training




Dripper Line Selection

Conventional dripper line



KISSS dripper line



Centre for Environmental Training




Dripper Laterals

- Typically buried at 100-150mm depth
- May be placed on surface beneath mulch
- Commonly pressure compensating (PC) and anti-siphon (AS) for sloping sites, or may be
- Non-pressure compensating for flat sites
- Laterals commonly spaced 0.6-1.0m apart depending on soil texture
- Space laterals more widely at bottom of slope
- Maximum 100m dripper line run length

Centre for Environmental Training



Dripper Spacing



Source: Netafim

Centre for Environmental Training



Pressure Compensation

- Flowrate from the drippers remains constant for varying in-line pressures. Why is this important?





Figure B1.4 Graph of pressure compensation of Netafim Ram dripline emitters.

Source: Netafim

Centre for Environmental Training



Pressure Compensating Emitters (PCDE)



Source: Netafim

Centre for Environmental Training



Operating Pressure and Flowrate

- Typical operating pressures - 5 to 40m.head
- Typical flowrate - 1.5 to 4.0L/hr per dripper (some brands specify flowrate per m)
- What factors should be considered when selecting emitter pressure and flowrate?

Dripper Line (Tube) Non-leakage Valve (DNL/TNL)

- Shuts off flow through the valve when line pressure drops below 2, 4 or 6m.head
- Opens and allows flow when the line pressure exceeds 8, 12 or 16m.head

Model	Shut-off pressure (m) **	Minimum Operating Pressure (m) **	Max. working Pressure (m)	Recommended Flow rate range (l/hr)
RED	2.0m (2.0m)	8.0m (4.0m)	40m	0-1,000
BLACK	4.0m (4.0m)	12.0m (7.0m)	40m	0-1,000
BROWN	6.0m (8.0m)	16.0m (11.0m)	40m	0-1,000



DNL/TNL Valve


- Holds pressure in the irrigation lines and keeps them filled
- Irrigation system full at the beginning of each irrigation cycle
- Ensures the system reaches operating pressure in the minimum time
- Prevents draining of the system to the lowest point
- Results in more uniform distribution of effluent

Airlocks / Air (Release) Valve

- Air release valves installed at high points to evacuate air from the laterals during system start-up
- Prevents a vacuum from occurring after pump turns off, avoiding debris intrusion into the drippers



Subsurface Irrigation System Schematic



Installation – Critical Phase

- Clear and detailed specifications
- Competent and experienced installers
- Follow manufacturers instructions / manuals
- Pipe installation to AS/NZS standards
- May need to rotary hoe or improve ground
- Protect against future damage
- Divert run-on stormwater
- Erect warning signs (min. 2)
- Fence off
- Observe OH&S requirements
- Make good



Commissioning

- Check pumps and aerators
- Fill pump well with clean water
- Pressure test all pipelines
- Check for leaks
- Check flush lines
- Check alarm system
- System should be inspected by regulator at this stage, not before or after

Centre for Environmental Training



Management of Irrigation Systems

- No household fittings or end of pipe discharge
- Do not irrigate low growing crops which are not cooked before eating
- Avoid compaction by vehicular and animal traffic
- Keep clear of sensitive receptors such as;
 - Clotheslines
 - Swimming pools
 - Barbeques
 - Children's play equipment
 - Open windows etc.

Centre for Environmental Training



Operation, Maintenance and Servicing Manuals

1. For home owner
2. For servicing agent:
 - Flushing – automated/manual
 - Regular monitoring and cleaning of filter(s)
 - Check for blockages, leaks and surface ponding
 - Monitor desludging requirements
 - Power outage procedures
 - Record keeping:
 - File as-built plans
 - Record location of pipelines
 - Record failures and problems
 - Service report to Council and copy to owner

Centre for Environmental Training



Summary

Design requires understanding of:

- Site specific details (soils, slope, flood and / or frost risk, landscape requirements, local regulations etc.)
- Nature of effluent being handled
- Equipment performance and interaction of components
- Clear understanding of required outcomes
- Careful hydraulic design required to match components and ensure even distribution

Centre for Environmental Training

