On-site Wastewater Management **Training Course**

Failing Systems

Auditing and Troubleshooting




Introduction

- No amount of desktop assessment can substitute for an inspection of an existing onsite wastewater system
- · Wide variation in designs and configurations makes standardised assessment a challenge
- · Inspectors need a sound knowledge of past and present technologies and working knowledge of basic physical and biochemical processes
- · Some of this can only be gained through field experience. Don't be afraid to have a look into a tank!









Occupational Work Health and Safety

- · WH&S Hazards around on-site systems:
 - Manual Handling
 - Infectious Material
 - Confined Spaces
 - Hazardous and Dangerous Substances
 - Electrical Injuries
 - Fatigue, Sunburn and Heat Stress



Work Health and Safety • Use of Personal Protective Equipment (PPE) is just one strategy for managing WH&S risks Centre for Environmental Training

Inspection Equipment

- · Inspection log sheets or digital log / notepad
- Basic tools such as screwdrivers, multi-grips, shifters, hammer etc.
- · Crowbar, torch and at least one bucket
- Sludge measuring device (e.g. Sludge Judge)
- · Measuring tape and camera
- · Sample bottles for water quality sampling



Inspection Equipment



Centre for Environmental Training



Inspection Equipment



Centre for Environmental Training

Inspection Equipment

- Dye (e.g. Fluorescein) for checking flow paths
- · Nessler's reagent (detects ammonia rich water)
- Imhoff cone or equivalent (activated sludge plants)
- Dissolved Oxygen (DO) or nutrient (N or P) test kits
- · Free residual chlorine test kit and pH strips

Centre for Environmental Training



Inspection Equipment







Centre for Environmental Training

What is the purpose of inspection?

- There are two main questions to ask during a performance audit or assessment
 - Is the system operating as it was designed to operate?
 - Is the system adequately managing risks to public health and the environment?
- The answer to these questions will sometimes be no for one and yes for the other



System Inputs

- What is the peak and average hydraulic load coming into the system?
 - Can use tables from AS/NZ 1547:2012 to estimate wastewater generation rates
 - If more scrutiny is necessary have a look at previous water bills
 - Wastewater typically makes up approximately 60-80% of the total water usage

Centre for Environmental Training



System Inputs

- · What sort of pollutant loads are entering the system?
 - Are there any activities going on that could cause influent to be different to typical domestic wastewater?
 - What sort of pressure is being put on the system by cleaning chemicals, detergents, disinfectants and antibiotics?

Centre for Environmental Training



System Inputs

- Premises that use, produce or generate food (dairy, brewery etc.) products can input high organic loads
- Beware unusual home activities and businesses e.g. hairdressing, catering
- Age and health of residents might impact on system performance e.g. use of chlorine bleach, high levels of drugs and antibiotics

Centre for Environmental Training



System Sizing

- · Sized for hydraulic load
- · Sized for sludge accumulation
- Sized for organic load (BOD)
- · Sized for nutrient load (if required)
- · General land capability assessment

Centre for Environmental Training



System Performance Indicators

- · Adequate removal of Suspended Solids
- · Adequate removal of BOD
- Pathogens
- Removal of nutrients?
 - Nitrogen
 - Phosphorus

Centre for Environmental Training

System Condition

· Structural integrity of all components?

































System Overflow / Leakage Centre for Environmental Training

Land Application System

- Effluent discharge (surface or groundwater)
- Suitable land application method?
- Suitable sizing?
- · Suitable location?
- Point of application in relation to water table?
- Buffers, separation distances, attenuation
 - Nutrients
 - Pathogens



















Audit Scenario

- Existing two (2) bedroom house (3 occupants) on town water supply
- Proposed construction of two (2) bedroom secondary dwelling (granny flat)
- 10ha rural residential lot on riverine corridor
- Existing development serviced by 2.5kL septic tank and gravity dosed (20m) absorption trench (0.6m w)
- Site soils = 400mm sandy loam over >300mm (weak) sandy clay loam over light/medium clay







Thoughts??

- · Why might we think this system is failing
 - Existing Load = $3EP \times 150L/p/day = 450L/day$
 - 2.5kL septic tank = >5 day HRT less accumulated sludge
 - Inlet and outlet tee's fitted?
 - Appropriate DLR for soil = 6-10mm/day (weak SCL) or LC?
 - Trench length = Q/DLRxW = 450/6 x 0.6 = 125m
 - Access to LAA?







Questions to Ask

- · Is primary treatment (septic tank) appropriate?
 - Lower effluent quality
 - Requires adequate soil depth and permeability (time) to achieve treatment standard
 - GW contamination / primary contact risk
- Is absorption trench land application appropriate?
 - Large area (LAA) requirement
 - Access / accidental damage risk

Centre for Environmental Training



Impact of changes??

- What impact will the proposed (granny flat) construction have?
 - Number of bedrooms increases from 2 to 4
 - Load = 6EP x 150L/p/day = 900L/day (>100%)
 - HRT reduction to septic tank
 - Continuing trench overload/failure
 - Effluent surfacing risk

Centre for Environmental Training



Solutions

- · What is an appropriate strategy to rectify/upgrade?
 - Primary or secondary treatment system?
 - Separate or combined treatment system for dwelling units?
 - Design hydraulic load?
 - Subsoil (absorption), Shallow (SSI, LPED) or Surface land application?
 - Any other mitigation or control measures to consider?

Centre for Environmental Training



Recommendation

- · Proposed OSSM servicing approach
 - Recommend 'secondary' treatment system for combined load (both dwellings) ~ 900L/day
 - Recommend pressure-compensating SSI
 - Soil Loading Rate based on soil horizon within 0.6m of POA
 - Appropriate DIR = 3.5mm/day (SCL)
 - Topsoil importation may be necessary
 - Required LAA = 260m²



Conclusions

- Don't be afraid to learn from plumbers, installers, designers and regulators with on-site experience
- Look at as many different systems as you can
- Be systematic and recognise the links between various processes
- Always keep an open mind about the possible cause of a problem

