

## On-site Wastewater Management Training Course

### Evapotranspiration Systems and Sizing by Water Balance

Centre for Environmental Training



## Terminology

Evapotranspiration Systems referred to as:

- Evapotranspiration Absorption Systems ETA – Australia (unlined)
- Evapotranspiration Seepage Systems ETS – New Zealand (unlined)
- Or simply Evapotranspiration Systems ET, if lined

Centre for Environmental Training



## Purpose

ETA/S Systems designed to:

- Maximise evapotranspiration
- Reduce absorption (drainage) in unlined systems
- Avoid absorption in lined systems
- Provide alternative to conventional trenches/beds in areas of low permeability soils (<0.5-1.5 m/d) e.g. clay loams, light, medium and heavy clays

Centre for Environmental Training



## AS/NZS 1547:2012

- Table L1 gives recommended DLRs of between 12 mm/d (CL) and 5 mm/d (LC/MC) based on soil texture
- Not necessary for annual evaporation to exceed annual precipitation
- Can use plant transpiration and void space storage to manage hydraulic load throughout seasons

Centre for Environmental Training



## AS/NZS 1547:2012

- DLRs are conservative values
- Any variation to be justified by full water balance for 12-month cycle (Appendix Q)
- No higher DLRs for Secondary treated effluent (may be better to use conventional trench or bed)
- Plant with grasses and shrubs which tolerate wet conditions and have high evapotranspiration capacity
- Construction outlined in Appendix L

Centre for Environmental Training



## Water Balance Design

- Background outlined in Appendix Q in AS/NZS1547:2012
- Main factors:
  - Effluent largely disposed of through deep infiltration, interflow and evapotranspiration
  - Evapotranspiration is significant but may not dominate water balance
  - Some deep infiltration is required to prevent salt build up
  - Not suited to shallow water tables unless using a lined system

Centre for Environmental Training




## Important Components of ET Bed Design

- Crop Factors (Cf), Evaporation (E) and Evapotranspiration (ET) – explained further in water balance example later
- Capillary Water – movement of water laterally and upwards under surface tension
- Field Capacity (FC) – upper limit of available water storage in soil / medium
- Void Ratio ( $n$ ) – proportion of bed available for water/air storage

Centre for Environmental Training



## AS/NZS 1547:2012 ETA Bed Design Detail




(Source: Standards Australia 2012)

Centre for Environmental Training



## 'Typical' ETA Bed Layout



Centre for Environmental Training



## ETA Bed Installed



Centre for Environmental Training



## Raised ETA Bed



Centre for Environmental Training



## Consideration of Climatic Data

- Pan evaporation (E)
  - From nearest climatically similar meteorological station
- Rainfall (R)
  - From nearest climatically similar meteorological station
- Or use SILO data:
- <https://www.longpaddock.qld.gov.au/silo/>

Centre for Environmental Training




## 'Class A' Evaporation Pan



Total historical station coverage nationwide:


- 17,875 rainfall stations
- Only 601 evaporation stations



(Source: BoM) Centre for Environmental Training

## 'Class A' Evaporation Pan

- Diminishing number of evaporation stations
- Move to SILO data (5km x 5km intersections)



(Source: BoM)

Centre for Environmental Training


## Nominal Monthly Area Requirement

Month	Pan evaporation E mm	Evapotranspiration ET ET=0.75E mm	Rainfall R mm	Retained rainfall R <sub>r</sub> =0.75R mm	LTAR per month mm	Disposal rate per month mm	Effluent applied per month L	Size of area m <sup>2</sup>
Jan	207.7	155.8	109	81.75	0	74.01	27900	376.90
Feb	170.8	128.1	119	89.25	0	38.85	25200	648.65
Mar	151.9	113.9	122	91.50	0	22.43	27900	1244.15
Apr	114.0	85.5	105	78.75	0	6.75	27000	4000.00
May	77.5	58.1	105	78.75	0	-20.63	27900	-1352.73
Jun	75.0	56.3	121	90.75	0	-34.50	27000	-782.61
Jul	80.6	60.5	69	51.75	0	8.70	27900	3206.90
Aug	108.5	81.4	84	63.00	0	18.38	27900	1518.37
Sep	141.0	105.8	39	44.25	0	61.50	27900	439.02
Oct	167.4	125.6	82	61.50	0	64.05	27900	435.60
Nov	192.0	144.0	76	57.00	0	87.00	27000	310.34
Dec	232.5	174.4	60	60.00	0	114.38	27900	243.93

Table 3. Calculation of area for each month (disregarding storage of effluent).

Centre for Environmental Training

## Inputs (Re) vs. Outputs (ET)



- ET dominates the WB, but not completely
- Excess rainfall can be managed for periods of the year provided that there is storage available in the system

Centre for Environmental Training

## Depth of Stored Effluent

Month	First total area m <sup>2</sup>	Application rate (3) mm	Disposal rate per month (4) mm	O1 - (4) mm	Increase in depth of stored effluent mm	Depth of effluent for month (K - 1) mm	Increase in depth of effluent mm	Computed depth of effluent month (K) mm
Dec	1000							
Jan		27.9	74.01	-46.11	-153.70	0	-153.70	= 0
Feb		25.2	38.85	-13.65	-45.50	0	-45.50	= 0
Mar		27.9	22.43	5.47	18.23	0	+ 18.23	= 18.23
Apr		27.0	6.75	20.25	67.50	18.23	+ 67.50	= 85.73
May		27.9	-20.63	48.53	161.77	85.73	+ 161.77	= 247.50
Jun		27.0	-34.50	61.50	205.00	247.50	+ 205.00	= 452.50
Jul		27.9	8.70	19.20	64.00	452.50	+ 64.00	= 516.50
Aug		27.9	18.38	9.52	31.73	516.50	+ 31.73	= 548.23
Sep		27.0	61.50	-34.50	-115.00	548.23	-115.00	= 433.23
Oct		27.9	64.05	-36.15	-120.50	433.23	-120.50	= 312.73
Nov		27.0	87.00	-60.00	-200.00	312.73	-200.00	= 112.73
Dec		27.9	114.38	-86.48	-288.27	112.73	-288.27	= 0

Table 4. Depth of stored effluent.

Centre for Environmental Training

## The Use of Water Balances

- Will work through an example of an unlined ETA bed
- Have provided templates for water balances for beds and also irrigation areas
- Once you have practiced the skills required in doing water balances longhand they lend themselves to setting up spreadsheets to speed calculation

Centre for Environmental Training

## Water Balance Exercise

- Calculate the minimum area and depth of an evapotranspiration-absorption/seepage area for a three bedroom / five person dwelling
- BoM rainfall and pan evaporation data

	JAN	FEB	MAR	APR	MAY	JUN	JUL	AUG	SEP	OCT	NOV	DEC
DAILY PAN EVAPORATION (mm)	6.3	5.4	4.4	3.3	2.1	1.8	2.0	3.1	4.3	5.4	5.9	7.0
MEAN MONTHLY RAINFALL (mm)	93.3	99.6	92.1	70.3	58.8	56.4	35.9	45.8	40.2	64.1	75.1	71.7

Centre for Environmental Training



## Water Balance Exercise

- Three test pits excavated on the proposed disposal area indicate that the soils are 475 mm weakly structured clay loam overlying moderately structured light clay to a depth of 2,000 mm. Use the recommended design loading rate derived from Table L1 of AS/NZS 1547:2012 (see the Field Workshop and Design Exercise section of these Course Notes)

Centre for Environmental Training



## Water Balance Exercise

- Calculate the evapotranspiration-absorption/seepage area using the worksheets provided on the following pages
- The evapotranspiration-absorption area is to be constructed of imported aggregate, is to have a maximum depth of 400 mm with a minimum of 50 mm freeboard (i.e. maximum depth of stored effluent is 350 mm)
- Conventional beds may have between 300 mm and 600 mm of aggregate, ETA/ETS beds 400 mm of aggregate and sand

Centre for Environmental Training



Calculation of evapotranspiration-absorption area size by water balance method

Size of area for each month

(1) Month	(2) Pan evaporation E mm	(3) Evapo transpiration ET ET = 0.75E mm	(4) Rainfall R mm	(5) Retained rainfall R <sub>r</sub> R <sub>r</sub> = 0.75R mm	(6) DLK per month mm	(7) Disposal rate per month (3)-(5)+(6) mm	(8) Effluent applied per month L	(9) Size of area (8)/(7) m <sup>2</sup>
Jan								
Feb								
Mar								
Apr								
May								
Jun								
Jul								
Aug								
Sep								
Oct								
Nov								
Dec								

First trial area = average monthly area = m<sup>2</sup>

Centre for Environmental Training



Depth of stored effluent (first trial)

(1) Month	(2) First trial area m <sup>2</sup>	(3) Application rate (8)/(2) mm	(4) Disposal rate per month (7) mm	(5) (3) - (4) mm	(6) Increase in depth of stored effluent (5)/n mm	(7) Depth of effluent for month (X - 1) mm	(7) Increase in depth of effluent + (6) mm	Computed depth of effluent month (X) mm
Dec		-	-	-	-	0		
Jan								
Feb								
Mar								
Apr								
May								
Jun								
Jul								
Aug								
Sep								
Oct								
Nov								
Dec								

n = effective void space factor. For imported durable aggregate, n = 0.3

Centre for Environmental Training



## Conclusions and Discussion

- Can use water balances to size/check size of all land application areas
- Previous example of unlined bed
- Slight modification for lined bed or trench (LTAR/DLR = 0)
- Similar water balance used for sizing irrigation areas but considers soil as an infinitely thin store (i.e. no soil storage) for conservative sizing

Centre for Environmental Training



## References

- Patterson RA, (2006). Evapotranspiration Bed Designs for Inland Areas. Septic Safe Technical Sheet Reference 05/15. NSW Department of Local Government, July 2006

Centre for Environmental Training

