

On-site Wastewater Management Training Course

Passive Dosing Systems

Siphons and Flouts, Low Pressure Effluent Distribution Systems

Centre for Environmental Training cet


Siphons

- Transform low or variable flows into regular doses
- Suitable for pressurising manifolds and drainfields
- Have no moving parts
- Require no electricity
- Technology over 100 years old
- Require understanding to ensure appropriate use and operation

Centre for Environmental Training cet


Various Siphons Available

- Stafford siphon
- Flowking
- ecoteam Surgeflow
- Ubi Aqua by ecoteam
- Orenco



Centre for Environmental Training cet


Dosing Siphon Anatomy



Centre for Environmental Training cet

Siphon Cycle


trap primed









Centre for Environmental Training cet

Vented to atmosphere


start and end of cycle



Centre for Environmental Training cet




Siphon Optimisation



- An outlet filter must be fitted to the septic tank
- Bell:trap volume approximately 3:1
- Bell diameter:trap pipe diameter approximately 3:1
- Deep trap easier to trigger
- Shallow traps need to be driven with high inflow rates
- Balance tube required for reliable resetting
- Calibration of relationship of balance tube ends important

Centre for Environmental Training cet

Siphon Operation



Source: Aris Wastewater Clinic


Centre for Environmental Training cet

Stafford Siphon Developed

- Reliably triggers at inflow rates < 0.2 L/m
- Reliably resets at inflow rates > 30 L/m



Use



Applications



- Domestic waste water treatment system, Martinsville, NSW
- One of two dosing siphons in the system

Centre for Environmental Training cet

Applications



- Cheese making waste treatment, Nimbin, NSW
- Doses a drainfield manifold with limited fall



Applications



Greywater septic tank to dosing chamber, near Nimbin, NSW

Centre for Environmental Training cet

Applications




Testing squirt height and uniformity, near Nimbin

Centre for Environmental Training cet

Flout


- Single flout
- Double flout
- Low drawdown possible with larger dose volume



- <http://www.flout.net/rissyplastics2/>
- <http://control.visionscape.com.au/page29091/Sales---Flout.aspx>

Centre for Environmental Training cet

Flout



Centre for Environmental Training cet

Flout dosing a sand filter



Centre for Environmental Training cet

Flout



Low Pressure Effluent Distribution (LPED) Systems

Definitions (AS/NZS1547:2012)

LPED Irrigation

- Shallow subsurface irrigation of effluent into topsoil through low pressure effluent distribution (LPED) lines

LPED line

- A pressure line perforated with drilled squirt holes and nestled in a distribution line

Centre for Environmental Training cet

LPED Irrigation

- Suitable for both Primary (with outlet filter) and Secondary effluent
- On moderate to flat slopes up to 10-15%
- Distributed into shallow trenches 200mm wide by 200mm deep, excavated in good quality topsoil
- Minimum 250mm topsoil depth required for application onto Category 5 or 6 soils

Centre for Environmental Training cet

LPED Irrigation

- Require dosed flow by siphon or Flout (low pressure) or pump (pressure) - not gravity fed
- Ensures even distribution along entire LPED trench; avoids spot loading of slotted pipe
- Facilitates hydraulic and nutrient uptake by transpiration and seepage
- Use sequencing valve to alternate loading of lines (pump only)

Centre for Environmental Training cet

LPED Irrigation

- Minimum 1,000mm spacing between LPED trenches
- Trenches constructed along the contour on sloping ground (max 15% gradient)
- All LPED systems should incorporate capacity for flushing (as per Figure M3)
- LPED systems require appropriate consideration of hydraulic design

Centre for Environmental Training cet

DIRs for LPED

| Soil Category | Soil texture | Structure | Drip and spray irrigation | LPED irrigation |
|---------------|----------------------|-----------|---------------------------|-----------------|
| DIR mm/day | | | | |
| 1 | Gravel and sand | -- | 5 | Not advised |
| 2 | Sandy loam | All | 5 | 4 |
| 3 | Loam | All | 4 | 3.5 |
| 4 | Clay loam | All | 3.5 | 3 |
| 5 | Light clay | All | 3 | 2.5 |
| 6 | Medium to heavy clay | -- | 2 | Not advised |



Centre for Environmental Training cet


LPED Irrigation

- Pressure line 25-40mm PVC with 3-6mm drilled holes at appropriate spacing for even distribution along whole length
- Clean water test to observe even squirt height before covering
- Distribution line Ag-pipe or slotted 100mm PVC

Centre for Environmental Training cet

LPED Irrigation



Centre for Environmental Training 

References

- The Flout Dosing Device. A device for gravity dosing of effluent or stormwater.
<http://control.visionscape.com.au/page29091/Sales---Flout.aspx>
- Arris Wastewater Clinic automatic dosing siphons
<https://www.arryswc.com.au/sample-page/automatic-dosing-siphons/>

Centre for Environmental Training 